



Remove any protective film that may be covering the laser scan window.

Touchscreen Calibration

If the touchscreen is not responding properly to stylus touch taps, the touchscreen may need to be recalibrated.

- 1) Tap the Start button in the lower left corner of the system tray.
- 2) Select Settings, then System.
- 3) Scroll the window if necessary and double tap the Screen icon.
- 4) Tap the “Align Screen” button and follow the instructions on the screen.

Set Date/Time/Time Zone

- 1) Tap the Start button in the lower left corner of the system tray.
- 2) Select Settings, and then Clock & Alarms
- 3) Use the left and right arrows at the top to navigate to the “Time” tab
- 4) Set the current date, time, and time zone.
- 5) Tap the “OK” button at the bottom of the screen.


Set Time Separator

- 1) In Settings, select System, and then select Regional Settings.
- 2) Use the left and right arrows at the top to navigate to the “Time” tab
- 3) Set the Time Style to “h:mm:ss tt”
- 4) If the “Time Separator” is not the colon “:” character, select the Time Separator box.
- 5) Select the “:” character from the drop-down list.
- 6) Tap the “OK” button at the bottom of the screen.


Set Short Date Format

- 1) In Settings, select System, and then select Regional Settings.
- 2) Use the left and right arrows at the top to navigate to the “Date” tab
- 3) Set the Short Date Style to “MM/dd/yyyy”.
 - a. If “MM/dd/yyyy” is not available please select “MM/dd/yy”.
- 4) If the “Date Separator” is not the “/” character, select the Date Separator box.
- 5) Select the “/” character from the drop-down list (or type it in using the on-screen keyboard).
- 6) Tap the “OK” button at the bottom of the screen.

Restarting the Scan Wedge


- 1) Tap the barcode icon in the system tray. 
- 2) Select Exit
- 3) Tap the Start button in the lower left corner of the system tray.
- 4) Select Power Tools
- 5) Select Scan Wedge (This should pop up saying it is initializing.)
- 6) Tap the “OK” button at the bottom of the screen.
- 7) The barcode icon should now show in the system tray. Tap on it.

Append Carriage Return to Barcode scan


- 1) Tap the barcode icon in the system tray.  If barcode icon is not there, complete steps 3 through 7 of Restarting the Scan Wedge
- 2) Tap on Settings.
- 3) Tap on the folder labeled Settings.
- 4) Double tap on SuffixKeys
- 5) Set the Value to 13

- 6) Tap "OK" button at the bottom of the screen.
- 7) Tap "File" in the bottom left of the screen.
- 8) Select Save
- 9) Tap "File" in the bottom left of the screen.
- 10) Select Exit
- 11) Restart The Scan Wedge (Please see Restarting the Scan Wedge)

To Use the Scan Wedge on the Handheld Desktop

- 1) Tap the barcode icon in the system tray.  If barcode icon is not there, complete steps 3 through 7 of Restarting the Scan Wedge
- 2) Scroll down until you see Blacklist
- 3) If the symbol next to it is a +, tap it to expand the folder.
- 4) Select Desktop
- 5) Uncheck all boxes here.
- 6) Tap "File" in the bottom left of the screen.
- 7) Select Save
- 8) Tap "File" in the bottom left of the screen.
- 9) Select Exit
- 10) Restart The Scan Wedge (Please see Restarting the Scan Wedge)

Enabling Symbologies

- 1) Tap the barcode icon in the system tray.  If barcode icon is not there, complete steps 3 through 7 of Restarting the Scan Wedge
- 1) Scroll down until you see Symbology
- 2) If the symbol next to it is a +, tap it to expand the folder.
- 3) Select the Folder of the symbology you would like to add
- 4) Check the box next to Enable Symbology
- 5) Tap "File" in the bottom left of the screen.
- 6) Select Save
- 7) Tap "File" in the bottom left of the screen.
- 8) Select Exit
- 9) Restart The Scan Wedge (Please see Restarting the Scan Wedge)

Microsoft Active Sync Installation (For Windows XP)

- 1) Locate a copy of the latest version of Active Sync for your computer system. The correct version is available from Microsoft's web site or a copy is included on your download. Version 4.5 is the latest from Microsoft as of this printing.
- 2) Look for the installation file (i.e. activesync_setup.msi) and run it. We recommend that you follow the installation instructions and accept the standard default settings during your install.
- 3) Leave Active Sync running to install and connect your handheld computer.

NOTE: Some users may use a single PC to connect multiple handheld computers. If this is the case, it is best to setup your PC to recognize each handheld as a "Guest". This avoids having Active Sync loading shared data from your Outlook and other PC applications. To set all connected handhelds as a Guest, please double-click and run the provided "GuestOnly.reg" file. It will instantly update your system for future connections.

Windows Mobile Device Center Installation (For Windows Vista or Windows 7)

- 1) Locate a copy of the latest version of Windows Mobile Device Center for your computer system. The correct version is available from Microsoft's web site or a copy is included in your download.
- 2) Look for the installation file (i.e. drvupdate-x86.exe) and run it. We recommend that you follow the installation instructions and accept the standard default settings during your install.

Install USB driver

BEFORE connecting the handheld computer to a host USB port for the first time, you must install the USB driver provided with the handheld computer on your PC. This will likely be include in the web download. Complete the driver installation as instructed during the installation procedure. (NOTE: Some handheld models may not require a driver to be loaded. Refer to the installation instructions.)

Connect the USB cable to your PC and the handheld or docking station (if provided). Windows will locate the hardware and complete the installation.

Install GigaTrak Handheld Application

The handheld application can be found in the handheld folder of your installation

- 1) Connect the handheld docking station to your computer (typically a USB connection) and plug in the AC power cable.
- 2) Put the handheld in the dock and wait for it to sync with the PC.
- 3) On the PC, double-click the handheld setup file for the application you are installing (e.g., setup_honeywell_hh.exe).

Connecting Wirelessly

- 1) Tap the Start button in the lower left corner of the system tray.
- 2) Select WLAN SWC
- 3) Select the tab at the bottom name Config
- 4) Tap Scan
- 5) Select your Wireless Internet.
- 6) Select Add at the bottom of the screen.
- 7) Give the Profile a name. Select Assoc Mode as your network configuration and enter other network security aspects such as the password as needed.
- 8) Click OK
- 9) Select the profile just created
- 10) Click Activate. The Status tab will now appear displaying the connection status.

Moving the Icon on the Start Menu

- 1) Find the TTS Icon. If the icon is not available follow the lettered steps below.
 - a. Tap the Start button in the lower left corner of the system tray.
 - b. Select File Explorer
 - c. Using the top left, go to My Device -> Program Files -> Tool Tracking System
 - d. Tap and Hold on the TTS Icon
 - e. Select Copy
 - f. Using the top left, go to My Device -> Windows -> Start Menu -> Programs
 - g. Tap and Hold on an open space
 - h. Select Paste Short Cut
- 2) Hold down on the icon until it highlights and lifts up.
- 3) Drag the icon to the new location.
- 4) Release the icon.

Reprogramming Soft Keys

- 1) Tap the Start button in the lower left corner of the system tray.
- 2) Select Settings.
- 3) Select Personal.
- 4) Select Buttons.
- 5) Select the Soft key you would like to change

- 6) Use the drop down menu below to select what you would like to assign to that soft key. Note: You can assign a soft key to start a program by selecting a program or as an alternate scan button by selecting <Scan2>.
- 7) Tap the “OK” button at the bottom of the screen.

Using the Camera

- 1) Tap the Start button in the lower left corner of the system tray.
- 2) Select Pictures & Videos.
- 3) Select Camera
- 4) Press the Up Arrow to zoom in and the Down Arrow to zoom out. Press Enter to take a picture.
- 5) Select OK to save the picture.
- 6) Select OK to return to the picture gallery.

Transferring Picture from the Handheld to the Computer

- 1) Connect the Handheld to the computer using Active Sync or Windows Mobile Device Center.
- 2) Select File Management.
- 3) Select Browser the contents of your device.
- 4) Open the folder named \
- 5) Open the folder named My Documents
- 6) Open the folder named My Pictures. (This is where the pictures taken with the handheld are stored.)
- 7) Select the pictures you want and copy them off of the handheld and on to the computer.

If the handheld does not respond properly, it may need a reboot. Perform a warm boot first and see if that fixes the problem. If it does not, then perform a cold boot.

Warm Boot the Handheld

Press the **Blue** key and the **Power** key simultaneously for about 6-7 seconds.

Cold Boot the Handheld (WARNING: This will require a reinstall and re-setup of the handheld)

Press the **Blue** key and the **Send** simultaneously for about 6-7 seconds.

